

# ALPINE ACV SERIES

## Alpine Modulating Control Valve IOM Manual



# Installation, Operating and Maintenance Manual – BT110-10 Modulating Level Control

The Modulating Pilot Can Be Fitted directly On To the Valve Or A Remote Reservoir Pilot c/w Counterweight Can Be Installed In The Reservoir

Address: 272 Bath Street Glasgow G2 4JR Cell: +44 (0) 776348 8809: Land: +44 (0) 1369 760423:

Email: [john@afcvalves.co.uk](mailto:john@afcvalves.co.uk): Web: [www.afcvalves.co.uk](http://www.afcvalves.co.uk)




## ULTRA / ALPINE SERIES

### BT110-10 Modulating Level Control

#### LEGEND

- 1 Upstream Ball valve
- 2 Y Strainer
- 3 Upstream Gauge
- 4 Flow Controller
- 5 Reservoir Ball valve
- 6 Modulating Level Pilot

**Note** U.C.V. may have an added feature of a bonnet ball valve which when in the closed position freezes the valve in its set position. Enabling work to be done on the control loop without closing the pipe line. This must remain open during normal operations



## FUNCTION:

The function of a Modulating level control valve is to maintain a constant level in storage tanks and reservoirs. Valve controlled flow into the tank is proportional to the discharge flow, keeping the tank full


## CONSIDERATIONS

- The water level should be as still as possible as the modulating pilot is sensitive to movement.
- If the water level is turbulent a stilling well should be added.
- The water pressure entering the tank should not be above 4 bar / 400Kpa.
- If the water pressure is too high, a fixed ratio valve should be added upstream of the valve.
- The sense line to the tank should be 3/8 inch – ½ inch ID.
- The valve should be installed as close to the tank as possible.

## COMMISSIONING ( Refer to drawing No 1 )

- Close the mainline Upstream and downstream isolating valves on either side of the valve.
- Set the flow controller ( No 4 ) to the halfway position ( Clockwise closing ).
- Close the reservoir ball valve ( No 5 ).
- Make sure the Upstream ball valve ( No1 ) is in the open position.
- Slowly open the upstream mainline isolating valve.
- Bleed off all accumulated air trapped inside the valve bonnet by loosening one of the gland nuts at the highest point on the valve.
- Open the downstream isolating valve. The valve should remain in the closed position.
- Open the reservoir ball valve. The valve should now open the line to the tank
- If the valve does not open: 1. Check the Modulating pilot is in the open position. 2. Close the Control Loop Flow Controller until the valve starts opening.
- **NOTE: The setting of the Flow controller is critical to the opening and closing of a level control valve**
- **Too far open and the valve will not open**
- **Too far closed and the valve will not close**

Drawing No 2



## PARTS LIST - SPECIFICATIONS

No	Description	Material	Standard
1	Body	Ductile Iron	GJS 500 – 7
2	Seat	Stainless Steel	AISI 304 / 316
3	O-ring	Rubber	NBR
4	O-ring	Rubber	NBR
5	Bolt	Stainless Steel	A2 / A4
6	Washer	Stainless Steel	A2 / A4
7	Bonnet	Ductile Iron	GJS 500 – 7
8	Bush	Bronze	C61900
9	Spring	Stainless Steel	AISI 304 / 316
10	Caulking Nut	Stainless Steel	A4
11	Diaphragm	Nylon Reinforced Rubber	EPDM + Nylon Fabric
12	Fixing Holder	Ductile Iron	GJS 500 – 7
13	Disc Holder	Ductile Iron	GJS 500 – 7
14	Seal	Rubber	EPDM
15	Seal Retainer	Stainless Steel	AISI 304 / 316
16	Stem	Stainless Steel	AISI 304 / 316
17	Plug	Stainless Steel	AISI 304 / 316
18	Screw	Stainless Steel	A2 / A4
19	Plug	Stainless Steel	A2 / A4
20	Washer	Stainless Steel	A2 / A4

## **MAINTENANCE ( Refer Drawing No 2 )**

The Ultra Modulating Level Control needs periodic maintenance of six months:

N.B. Make sure there is no pressure In or directly upstream of the valve - Use the mainline isolating valves to ensure personnel safety

- Check the tightness of the Control Loop fittings
- Check the flanges for leaks
- Remove the bonnet and check the diaphragm ( 11 ) for Rips or damage
- Lift the diaphragm assembly out
- Check the O Rings ( 3 & 4 ) and seal ( 14 )
- Check the Disc Holder ( 13 ) for cavitation wear

## **TROUBLE SHOOTING GUIDE**

### Valve refuses to open

- Stem Jammed or blockage on top of stem
- Blockage on the downstream Control Loop
- Leak on the upstream Control Loop
- Diaphragm torn
- Reservoir ball valve closed
- Modulating Pilot blocked or damaged
- Low upstream pressure

### Valve Refuses to close

- \* Debris underneath the stem
- Blockage on the upstream Control Loop
- Leak on the downstream Control Loop
- Torn Diaphragm
- Upstream ball valve closed