

ALPINE ACV SERIES

AFC Surge Anticipating Control Valve IOM Manual



Installation, Operating and Maintenance Manual – BT116-52 Surge Anticipating Valve

Address: 272 Bath Street Glasgow G2 4JR Cell: +44 (0) 776348 8809: Land: +44 (0) 1369 760423: Email: john@afcvalves.co.uk: Web: www.afcvalves.co.uk



ULTRA/ALPINE SERIES

BT116-52 Surge Anticipating Valve

LEGEND

- 1 Upstream sense line ball valve
- 2 Upstream sense line strainer
- 3 Upstream sense line gauge
- 4 Upstream sense line Flow controller
- 5 Relief pilot valve P500
- 6 Anticipator pilot P20A
- 7 Test ball valve
- 8 Downstream ball valve



FUNCTION : To prevent water hammer and the resulting pressure surge on pump trip. When a pump trips the column continues to move, creating an area of low pressure behind it, then returns as a high pressure wave which can cause severe water hammer resulting in damage to piping, fittings and pumps.

CONSIDERATIONS : A surge anticipating valve can release a fair amount of water when it is operating. To save water a discharge line should be added downstream into a tank With a upstream and downstream isolating valve on either side of the surge anticipating valve

COMMISSIONING :

- Close the mainline upstream and downstream isolating valves on either side of the control valve
- Set the flow controller (No 4) to the halfway position (Clockwise closing). This valve controls the closing speed of the control valve (the further closed the slower the response]
- Close the downstream ball valve (no 8)
- Slowly open the upstream mainline isolating valve.
- Bleed of all accumulated air trapped inside the valve bonnet by loosening one of the gland nuts at the highest point on the valve.
- Turn the adjustment screw of the high pressure pilot P500 (No 5) all the way in (clockwise).
- Turn the adjustment screw of the low pressure pilot P20A (No 6) all the way out (anti-clockwise).
- Open the mainline downstream isolating valve The control valve should remain closed.
- Open the downstream ball valve (No 8) The control valve should still remain closed.
- With the line in the static state (Pumps stopped) Close the upstream sense line ball valve (No 1)
- Using the test ball valve (No 7 } Lower the pressure on the upstream sense line gauge (No 3) by 2 Bar
- Keeping (No 1) ball valve closed, turn the adjustment screw of the low pressure pilot P20A (No 6) in clockwise until the control valve starts opening, then stop turning.
- Allow the valve to open, then slowly open the sense line ball valve (no 1), the valve should close The P20A pilot will now sense a 2 Bar Pressure drop in the mainline and open
- With the line in the dynamic state (Pumps running) Turn the adjustment screw of the high pressure pilot P500 (No 5) out anti-clockwise until the control valve starts opening
- Then turn the adjustment screw of the P500 in clockwise one full turn the control valve will close The P500 will now keep the control valve open until the high pressure wave dissipates, then close the control valve

Drawing No 2





PARTS LIST - SPECIFICATIONS

No	Description	Material	Standard
1	Body	Ductile Iron	GJS 500 – 7
2	Seat	Stainless Steel	AISI 304/316
3	O-ring	Rubber	NBR
4	O-ring	Rubber	NBR
5	Bolt	Stainless Steel	A2 / A4
6	Washer	Stainless Steel	A2 / A4
7	Bonnet	Ductile Iron	GJS 500 – 7
8	Bush	Bronze	C61900
9	Spring	Stainless Steel	AISI 304 / 316
10	Caulking Nut	Stainless Steel	A4
11	Diaphragm	Nylon Reinforced Rubber	EPDM + Nylon Fabric
12	Fixing Holder	Ductile Iron	GJS 500 – 7
13	Disc Holder	Ductile Iron	GJS 500 – 7
14	Seal	Rubber	EPDM
15	Seal Retainer	Stainless Steel	AISI 304 / 316
16	Stem	Stainless Steel	AISI 304 / 316
17	Plug	Stainless Steel	AISI 304 / 316
18	Screw	Stainless Steel	A2 / A4
19	Plug	Stainless Steel	A2 / A4
20	Washer	Stainless Steel	A2 / A4

MAINTENANCE (Refer Drawing No 2)

The Ultra Surge anticipating valve needs periodic maintenance of 1 - 2 years. Depending on the severity of operation N.B. Make sure there is no pressure In or directly upstream of the valve - Use the mainline isolating valves to ensure personnel safety

- Check the tightness of the <u>Control Loop</u> fittings
- Check the flanges for leaks
- Remove the bonnet and check the diaphragm (11) for Rips or damage
- Lift the diaphragm assembly out
- Check the O Rings (3 & 4) and seal (14)
- Check the Disc Holder (13) for cavitation wear

TROUBLE SHOOTING GUIDE

Valve refuses to open

- Stem Jammed or blockage on top of stem
- Blockage on the downstream Control Loop
- Leak on the upstream Control Loop
- Diaphragm torn
- Downstream ball valve closed
- · Pilot valves blocked or damaged
- Low upstream pressure

Valve Refuses to close

- * Debris underneath the stem
- Blockage on the upstream Control Loop
- Leak on the downstream Control Loop
- Torn Diaphragm
- Upstream ball valve closed