

# ALPINE ACV SERIES

## AFC Altitude Level Control Valve IOM Manual



A10A Altitude Valve



Altitude Pilot



Accelerator  
(optional)


Installation, Operating and Maintenance  
Manual – A10A-Altitude Level Control Valve





## BT127-1 Altitude Level Control Valve

### LEGEND

- 1 Upstream ball valve
- 2 Y Strainer
- 3 Upstream gauge
- 4 Bonnet Flow Controller
- 5 Pilot P10A Flow Controller
- 6 Altitude Pilot P10A
- 7 Downstream ball valve
- S P10A Supply
- B P10A Bonnet
- D P 10A Drain



DRAWING No 2



**FUNCTION :** To maintain the upper and lower water levels in a reservoir at pre-set water levels.

**CONSIDERATIONS :**

- The pressure entering a reservoir should not be above 4 Bar / 400Kpa
- If the upstream pressure is above 4 Bar / 400KPa. A Pressure Reducing valve or a Fixed Ratio valve should be installed upstream of the Altitude valve
- The OD of the sense line should be  $\frac{1}{2}$  inch –  $\frac{3}{4}$  inch in diameter
- The sense line should be connected to the bottom of the reservoir away from inlet or outlet valves


**COMMISSIONING : Refer to drawing No 1 & 2**

- Close the upstream and Downstream isolating valves on either side of the control valve
- Set flow controllers ( No 4 & 5 ) to the halfway position ( Clockwise closing )
- Close the downstream ball valve ( No 7 )
- Make sure the upstream ball valve ( No 1 ) & the setting ball valve are in the open position
- Slowly open the upstream mainline isolating valve
- Bleed off all the accumulated air trapped inside the bonnet of the control valve by loosening one of the gland nuts at the highest point on the valve
- Turn the adjusting nut of the altitude pilot ( No 6 ) all the way out ( Anti – clockwise )
- Open the downstream mainline isolating valve. The valve should remain in the closed position.
- Close the pilot setting ball valve
- Remove the bonnet connection from the altitude pilot ( B )
- Lead a temporary sense line from the altitude Pilot ( No 6 ) to the bottom of the reservoir from there to the upper required water level
- Connect the temporary sense line to the bottom of a clear plastic bottle so it shows the water level in the sense line
- Pour water into the bottle until the water is visible in the bottle, allow the air bubbles to escape. Hold the bottle at the required upper water level
- Turn the adjusting nut of the altitude pilot in ( clockwise ) until water spurts out of the bonnet connection of the altitude pilot
- Drop the temporary sense line the spurting will stop.
- The upper altitude pilot is now set to close the control valve when the upper required water level is reached
- The altitude pilot is factory set to re-open after the water level has dropped 1.5 meters
- Re-connect the bonnet connection on the altitude pilot ( B ). Open the pilot setting ball valve
- Connect the altitude pilot sense line to the reservoir sense line
- Slowly open the downstream ball valve ( No 7 )
- The control valve will now allow flow into the reservoir

**BALL VALVE CONTROL**

Closing Upstream ball valve No 1, will open the valve manually  
Closing Downstream ball valve No 7, will close the valve manually  
Closing the pilot setting ball & The Downstream ball valve, will allow work on the altitude pilot

# Drawing No 3



## PARTS LIST - SPECIFICATIONS

No	Description	Material	Standard
1	Body	Ductile Iron	GJS 500 – 7
2	Seat	Stainless Steel	AISI 304 / 316
3	O-ring	Rubber	NBR
4	O-ring	Rubber	NBR
5	Bolt	Stainless Steel	A2 / A4
6	Washer	Stainless Steel	A2 / A4
7	Bonnet	Ductile Iron	GJS 500 – 7
8	Bush	Bronze	C61900
9	Spring	Stainless Steel	AISI 304 / 316
10	Caulking Nut	Stainless Steel	A4
11	Diaphragm	Nylon Reinforced Rubber	EPDM + Nylon Fabric
12	Fixing Holder	Ductile Iron	GJS 500 – 7
13	Disc Holder	Ductile Iron	GJS 500 – 7
14	Seal	Rubber	EPDM
15	Seal Retainer	Stainless Steel	AISI 304 / 316
16	Stem	Stainless Steel	AISI 304 / 316
17	Plug	Stainless Steel	AISI 304 / 316
18	Screw	Stainless Steel	A2 / A4
19	Plug	Stainless Steel	A2 / A4
20	Washer	Stainless Steel	A2 / A4

## **MAINTENANCE ( Refer Drawing No 3 )**

The Ultra Altitude level control needs periodic maintenance of 1 – 2 years depending on operating severity

N.B. Make sure there is no pressure In or directly upstream of the valve - Use the mainline isolating valves to ensure personnel safety

- Check the tightness of the Control Loop fittings
- Check the flanges for leaks
- Remove the bonnet and check the diaphragm ( 11 ) for Rips or damage
- Lift the diaphragm assembly out
- Check the O Rings ( 3 & 4 ) and seal ( 14 )
- Check the Disc Holder ( 13 ) for cavitation wear

## **TROUBLE SHOOTING GUIDE**

### Valve refuses to open

- Stem Jammed or blockage on top of stem
- Blockage on the downstream Control Loop
- Leak on the upstream Control Loop
- Diaphragm torn
- Reservoir ball valve closed
- Altitude Pilot blocked or damaged
- Low upstream pressure

### Valve Refuses to close

- \* Debris underneath the stem
- Blockage on the upstream Control Loop
- Leak on the downstream Control Loop
- Torn Diaphragm
- Upstream ball valve closed